


**INSTALLATION INSTRUCTIONS**

- A. PLACE LEAD FLASHING ① IN PROPER LOCATION TO ACCOMMODATE FUTURE ROOF PENETRATIONS.
- B. FOLLOW RECOMMENDATIONS FROM ROOFING MATERIAL MANUFACTURER FOR SEALING LEAD FLASHING TO ROOF.
- C. USING E/S SUFFIX OPTION -PS PERMASEAL ③ OR GE TYPE II SILICON RUBBER CAULK OR EQUAL, PLACE A STRIP OF PERMASEAL OR BEAD OF CAULK AROUND THE TOP OF THE LEAD FLASHING.
- D. PLACE PLASTIC FUTURE COUNTERFLASHING ④ OVER ROOF PENETRATION AND DOWN ONTO THE SEALANT LEAVING ABOUT 3/8" SPACE FOR EXPANSION AND CONTRACTION.

 ACORN ENGINEERING COMPANY P.O. BOX 3527 INDUSTRY, CA. 91744 (626) 336-4561 FAX (626) 961-2200	TITLE <b>910 SERIES FUTURE FLASHING</b>	
	MANUFACTURE DATE <b>SEPTEMBER 1996</b> <b>TO PRESENT</b>	DATE ISSUED <b>9/23/96</b> DATE REVISED <b>12/15/97</b>